User Manual

IT-400

Dear Customer

Thank you very much for buying our product. This user's manual is to insure your prompt and convenient use of the product. Please read the user's guide carefully before you use our product.

Content

Foreword 1

Product Specification 3

Appearance and Button 4

First Use 5

Desktop 6

Main Menu Operations 8

Application Management 8

Connection with PC 18

Trouble Shooting 19

Foreword

1. Acknowledgements

Thank you for choosing our MID (Mobile Internet Device) products. This is a kind of mobile internet equipment, delicate and cabinet, easy to carry. Equipped with a high resolution 800×480 LCD touch screen, can see high-definition video and image support to install multiple office, entertainment applications etc. The dazzle cool interface can let you have new user experience.
Please read the manual carefully before using Device.

2. Announcements

Maintenances
●Please keep Device dry. Do not let equipment, battery charger contact water and vapor, or use wet hand to operate equipment or charger, Lest cause short-circuit, corrosion caused by equipment failure, and personnel.
●Don't make equipment, battery and charger strongly impact or vibration. Lest cause equipment, battery and charger fault, fire or explosion.
●Don't put this equipment, battery and charger in the too high or too low temperature region. Otherwise you may cause equipment, battery and charger fault, fire or explosion.
●Don't hit, throw, acupuncture the Device, and avoid drop, extrusion, bending Device.
●Don't unauthorized equipment and accessories, otherwise the equipment and accessories will not in the company's warranty scope.

3. Safety Tips

Before you see the Device, please read this section information, and let your child know these information. For detailed information, please refer to the Safety

guidelines and note:

●Do not use Device in driving, in order to prevent the safe driving.

●In medical sites, please comply with relevant provisions or regulations. Please close Device near the medical equipment area.

●Please close Device or open planes mode when you are boarding, to avoid wireless signals jamming aircraft control signal.

●Please close Device near the use of high precision electronic equipment; otherwise it may lead to electronic equipment disabled.

●Do not unauthorized to remove Device and accessories. Only authorized institutions can repair this Device.

●Please put Device away from magnetic equipment. The radiation of Device will erase information which is on magnetic storage device.

●Please don't use Device in the high temperature and flammable areas (such as near gas station).

●Please don't put Device and accessories in this place which children can touch it, please do not let the child use Device in unsupervised.

●Please abide by the relevant laws and regulations when you use the Device, and respect others lawful rights and privacy.

●Please strictly abide by relevant specification of this manual when you use USB cable. Otherwise it might damage your Device or personal computer.

●Please don't use Device in the damp environment such as bathroom etc. And avoid the Device soaked or flushed by the liquid.

Product Specification

CPU	A10 ARM Contex-A8 1.5GHz
Screen	7” 800×480 Five point capacitive-touch
OS	Android 4.0 Ice Cream Sandwich
Memory	512MB DDR3
Storage	4GB NAND Flash
TF Card	Expandable to 32GB Micro SD Card
Wireless	Wi-Fi 802.11 b/g
Camera	0.3MP Front
Battery	2000mAh
G-Sensor	Built-in 3D gravity sensor
USB	USB high speed 2.0
HDMI	HDMI & CVBS Output to HDTV
Audio	MP3, WMA, OGG, FLAC, APE, AAC, AC3, ATRA, DTS, etc.
Video	RMVB, WMA, ASF, MP4, 3GP, AVI, MKV, DIVX, MPEG-2, etc.
Game	Support several of entertainment games based on Android platform.
E-book	Assemble e-book tool to read based on Android platform
Office	Support various of office software based on Android platform

Appearance and Button

1.Vol+: Press to increase the volume of headphones or speakers.

2.Vol-: Press to reduce the volume of headphones or speakers.

3.Power: If turned off, press two seconds to start the system. If turn on, short press can lock and unlock the screen, long press two seconds there will be “Power Off” selection.

【NOTE】In the case of software crashes, long press “Power” for 8 seconds, the device will be forced to shut down. This function is suggested only in system halted. Otherwise it’s not recommended, or it will easily damage the system.

4.Camera: Front camera can be used for video chat and video telephony.

5.Back: Short press to return to the previous page.

6.Home: Short press to return to the desktop.

7.Menu: Short press to open the current screen or application options menu.

8.Mic: Recording or Internet phone call.

9.Headphone jack: External 3.5mm high fidelity headphones can listen to music.

10.HDMI interface: Can be connect to a TV with high definition video signal output.

11.USB interface: Mini 5pin USB interface, through the USB cable or OTG cable to connect the computer copy data or install applications.

12.DC charging interface: Can connect adapter to charge.

13.TF Card slot: External Micro SD card, up to 32GB.

14.Speaker: By default is turned on, it will be turned off when insert the headphone.

First Use

Battery Management and Charging

●Please make sure that the device battery is fully charged on first usage.

●Just plug the charger into DC interface for charging.

●Keep the first two charging about 6 hours. And around 4 hours next time.

【NOTE】This item was featured with built-in polymer battery, the charger should be comply with the specification of Input: AC100-240V, 50/60Hz, Max:0.3A. Output: DC5V/2A.

●The battery icon will scroll during charging.

●Screen battery icon will turn green and stop scrolling when charging completed.

●To extend the battery life, suggest run out of the power in the first two times.]

【NOTE】If the device is no used for a long time, make sure the machine will be charged one time within one month, to avoid excessive consumption.

●On lower power shutdown, plug the charger, the machine tips “lower power” and “charging”, the device will enter to the menu if there is enough power.

●It’s better to charge in standby, otherwise the changing time will be longer, as the screen consume battery during charging.

Desktop



Press the Power button, after ten seconds will enter the interface of unlock the screen. Hold , slide to right, the icon will turn to and the screen will unlocked.



After the system is started up, you can see Android system desktop (refer to the picture below), the default system desktop: status bar, instant search button, main menu icon and shortcut icon.

Icon	Name	Description
	Back	Opens the previous screen you were working in, even if it was in a different app. Once you back up to the Home screen, you can’t go back any further in your history.
	Home	Opens Home. If you're viewing a left or right Home screen, opens the central Home screen.
	Recent apps	Opens a list of thumbnail images of apps you've worked with recently. To open an app, touch it. To remove a thumbnail from the list, swipe it left or right.
	Others	You can choose a picture to set wallpaper, enter the interfaces of Manage apps and system settings.
	Apps	Opens the list of apps, the main menu will be from right to left.
	Search	Quick search icon for web search by typing key words.
	Status	The status bar to display the current system of network status, battery, time information.

Main Menu Operations

In the main menu, you can set up system, run the available application program, install new application program and start music playing, video playing, website browsing, playing games etc.



●To move an icon to the Desktop screen, touch & hold on the icon, then release it when it appears on the Desktop screen.

●Touch, hold the icon for 3 seconds, press Remove, then will delete it from the Desktop.

Application Management

Install Android Applications

●There are many interesting and free Android applications that can be found on the web. Just launch your web browser and do search for Android apps.

Purchased or free Android applications that you have downloaded to your

computer can be installed quickly and easily on your Tablet using the **File Manager** application.

1. Copy the *.apk* files that you want to install onto a SD card or USB device, insert or connect to your device.

2. Tap the **File Manage**r application icon, and find out the *.apk* file, tap on it and select Install. The application is installed and the application icon is added to the **Applications** screen.

Uninstall Android Applications

●You can also quickly and easily uninstall the Android applications that you have installed.

1. Tap **Settings** →**Applications** → **Manage applications**.

2. Tap the application you want to uninstall → **Uninstall**.

3. Tap **OK** to confirm the install.

CLOCK

●Tap the **Clock** application icon. You can use your device as an alarm clock by setting multiple alarms.

1.Tap **Set Alarm** → **Add Alarm**, set up your alarm as desired.

【NOTE】If you don't select a repeat, the alarm is automatically deleted after it is activated.

2. Tap **Turn On Alarm** → **OK** →**Done.**

●When a scheduled alarm is activated, a pop-up window with the alarm title appears. Tap **Snooze** if you want to be reminded again in 10 minutes. Tap **Dismiss** to cancel the alert.

PLAY STORE

●The **Play Store** has many applications that you can quickly and easily download to your Tablet.

1. Tap the **Play Store** application icon.

The first time, you are prompted for your **Play Store** login information. If you have not yet registered an account, tap **Register**. Otherwise, tap **Login** and enter your login information and then tap **login** again.

2. You can select applications from the default Featured group, by Categories, Top (latest, hottest, random), or search by name.

3. Tap on an application, → **Download**.

4. After the app is downloaded, tap **Install**.

5. Tap **Open** to launch now, or **Done** to return to the **Play Store** screen.

After downloading apps, tap on **History** to manage the installed applications. You can add and/or view comments from other users, launch apps, and uninstall them.

BROWSER

●Users can connect to the Internet through a browser.

●Click the **Browser** icon, and then you can open the Web browser.


youtube - Google Search
http://www.google.com.hk/search?hl=en&newwindow=1&safe=strict&tbo=d&site=i
+You Search Images Videos Maps Translate Gmail More
Sign in
Google
youtube
Everything Images Videos News More
YouTube - Broadcast Yourself.
www.youtube.com/
Share your videos with friends, family, and the world.
Music
Watch music videos from all of your favorite artists ...
Upload
Upload and share your own videos with the ...
Movies
Watch feature length movies, shorts, and ...
BarackObamadotcom
Join Barack Obama's Campaign today ...
Project Glass: One ...
We believe technology should work for you — to ...
homeproject
TO DEBATE AND TAKE ACTION http://www ...
8:29

CALENDAR

●For the first time to using the **Calendar**, you need to add an Exchange account. Enter account email address and password. Click **Next** and follow the prompts to complete the account configuration. Then you can use the Calendar.

Add Event

1. On the **Calendar** screen, tap on the date to which you want to add an event.
2. Tap on the event time, tap in each entry field to enter the desired event information.
3. Tap **Done.**

【NOTE】Dates with green bars indicate scheduled events.

CAMERA

1. Take Pictures

In Camera, is the status of taking pictures, tap to take the picture.

The picture will be saved.

2. Take Video

Tap switch to video, and you can take videos.

Tap to begin and tap to stop. The video will be saved.

CALCULATOR

1.Tap the **Calculator** application icon.

2.Tap the numbers and sign of operation to do the calculation.

3.Tap **CLR** to clear the result.

EMAIL

POP3 and **SMTP** accounts are supported.

●You can enter one or more personal email address that you would like to access through your Tablet.

1.Tap the **Email** application icon.

2.Tap in the **Email address** entry field, enter your email address.

3.Tap in the **Password** entry field, enter your email password.

4.Tap **Done**.

5.**Manual Setup** (Optional): The server settings are automatically populated based on your email account provider (i.e., gmail.com, etc.). However, if you need to change the server settings tap Manual Setup and make necessary changes.

MUSIC

Audio file formats supported: MP2, MP3, WAV, AAC, WMA, etc.

1.Tap the **Music** application icon.

2.Select an audio file from Artists/Albums/Songs/Playlists to play it.

HD PLAYER

Video file formats supported: MPEG1/2/4, MJPG, H264, etc.

1.Tap the **HD Player** application icon.

2.Select a video file to play.

3.Tap on the screen to display video controls (adjust volume, pause/play, previous/next, adjust brightness).

SETTINGS



Wireless & Networks	Wi-Fi	Turn on Wi-Fi
	Data usage	Mobile data/Set mobile data limit/Data usage cycle
	More	Airplane mode/Ethernet/VPN/Mobile networks
Sound	Volumes	To adjust the Media volume, Alarm volume and Notification volume.
	Default Notification	Select desired ringtone sound.

	Vibrate and ring	Select vibrate and ring
Display	Brightness	Tap & slide to adjust the screen brightness as desired, and then tap OK.
	Wallpaper	HD Player/Live wallpapers/Wallpapers
	Auto-rotate screen	When selected, the orientation of the screen switches between Portrait and Landscape automatically when you rotate the device.
	Sleep	Adjust the delay time before the screen automatically turns off.
	Font size	Adjust the size of font.
	Accelerometer coordinate system	Accelerometer uses the default coordinate system.
	Screen adaption	Used to adjust size of some games display screen.
Storage	Internal Storage	Total space/Apps space/Available space
	Erase SD card	Erases all data on the SD card, such as music and photos.
	ExtSD	Mount SD card, enable media scanning on extSD.
	USBhost1	Mount SD card, enable media scanning on usbhots1.
Battery	Battery usage data	
Apps	Downloaded/ On SD card/ Running/ All	
Accounts & sync	Sync on the account information.	
Location	Google's	Let apps use data from sources such as

Services	location service	Wi-Fi and mobile networks to determine your approximate location.
	Location & Google search	Let Google use your location to improve search results and other services.
Security	Screen Security	Screen lock/Owner info
	Encryption	Encrypt tablet
	Passwords	Make passwords visible
	Device Administration	Device administrators/Unknown sources
	Credential Storage	Trusted credentials/Install from SD card/Clear credentials.
Language & Input	Language	Select the language and region according to your location./Spelling correction/Personal dictionary.
	Keyboard & Input methods	Default/ Android keyboard
	Speech	Text-to –speech output
	Mouse/Trackpad	Pointer Speed
Backup & Reset	Backup & Reset	Back up my data/Backup account/Automatic restore
	Personal Data	Factory data reset
Date & time	Automatic date & time	Use network-provided time
	Automatic time zone	Use network-provided time zone
	Set date	Set the date
	Set time	Set the time

	Select time zone	Select the time zone
	Use 24-hour format	You can choose to use 24-hour format or 12-hour format.
	Select date format	You can select the date format.
Accessibility	Services	Choose the services you have installed.
	System	Large text/Auto-rotate screen/Speak passwords/Touch & hold delay/Install web scripts.
Developer options		USB debugging/Development device ID/Stay awake/Allow mock locations/HDCP checking/Desktop backup password
	User Interface	Strict mode enabled/Pointer location/Show touches/Show screen updates/Show CPU usage/Force GPU rendering/Window animation scale/Transition animation scale
	Apps	Don’t keep activities/Background process limit/Show all ANRs
About tablet	System updates/Status/Legal information/Model number/Android version/Baseband version/Kernel version/Build number	

Connection with PC

USB Connect

Use USB cable to connect device to PC, device will pop up the USB connection window, click Turn on USB storage to connect to PC.


USB Mass Storage
USB connected
You have connected to your computer via USB. Touch the button below if you want to copy files between your computer and your Android's SD card.
Turn on USB storage
8:37

Into the load mode, you can copy, delete the file on the device and the file on the memory card.

OTG Using

●Support FAT32 format mobile memory devices such as USB disk.

●The way for Plug and play.

●Use OTG cable to connect MID USB OTG PORT with other device.

Trouble Shooting

●Device fails to turn on.

* Check battery volume.
* Connect to adaptor, and double check.
* If device fail to start up after charging, please contact distributors.

●Twinkling screen after turn-on or sudden shut off after starting up.

* Battery low, please charge the device.

●No sound via earphone.

* Check if volume is set at the lowest.
* Check if audio file is damaged. Play other audio to reconfirm. Damaged file may result in noise or staccato only.

●Copy function is not working, fail to play music.

* Check if PC and device is proper corrected.
* Confirm whether storage space is full.
* Confirm whether USB cable is damaged.
* Confirm whether USB is out of connection.